



CAUTION:

- · Use the blank terminals for machanical support only.
- The blank terminals must not be connected any copper on PC board.
- Be sure to electrically isolate from negative the positive terminals.